

Voice control of blinds with Amazon Alexa



"Alexa, open the blinds"

The voice control of the equipment allows orders to be executed by voice according to a well-defined structure. Practical and fun, you won't be able to do without it as long as you know the best practices!

To take full advantage of this additional functionality and avoid unnecessary questioning, simply follow a few rules for structuring your orders:

- **Synchronize your equipment**
Just say the command "Alexa, discover my devices" to synchronize your Tydom equipment, compatible with Amazon Alexa.
- **Begin your sentences with "Alexa "**
Amazon's voice assistant is activated when the word "Alexa" is pronounced. It then listens to a command.
- **Use action verbs**
For the requested command to be executed correctly, the command must be expressed by an action verb. In the case of blind or shutter control, the commands "open", "close", "raise", "lower" or "lower" are required for correct interpretation of the voice assistant.
- **Name your equipment precisely**
To control the blinds by voice, the voice assistant has been previously associated with Tydom application in which your connected equipment is registered. To carry out your order, you need to quote the exact name of the equipment, as named in Amazon Alexa.

For example, you wish to open the living room blind.

This equipment must have been named "Living room blind" in Tydom.

Amazon Alexa will then execute the command when listening to the phrase "Alexa, open the living room blind".

Please note that voice control does not apply to safety equipment.

Amazon's security policy excludes voice control of gates, front doors or garage doors.

To control these devices remotely, you can of course use Tydom application on your smartphone.

And if these tests remain unsuccessful, please [contact us](#). Our advisers are at your disposal 6 days a week.

Enjoy your discovery!

Delta Dore customer service